

Protective Features

1. Automatic cutoff: After 15 seconds of use the device will cease firing and the LED light will flash both blue and orange ten times.
2. Short circuit protection: If the K2 detects a short circuit the device will immediately cease firing and the light will flash both blue and orange three times.
3. Low voltage protection: When the K2's charge drops to 3.2 volts the LED will flash orange fifteen times and the device will stop functioning.
4. Overcharge protection: When the battery has fully charged to 4.2 volts the K2 will automatically stop charging.
5. High temperature protection : If the control board detects its temperature over 167 degrees Fahrenheit/75 degrees Celsius the device will cease functioning, the LED light will turn both orange and blue for 3 seconds.

Specifications

1. K2 tank capacity: 1.8ml
2. K2 atomizer: Kanthal 1.60 ohm
3. K2 battery capacity: 800 mah
4. K2 battery output voltage: 5.5V (without atomizer)

Charging Instructions

When the usb cable is attached and the K2 begins charging the button will flash blue and orange three times. While charging the LED will indicate the K2's current charge status, 3.5 volts or less will be indicated by an orange light, 3.5 to 3.8 volts is indicated by a blue light, charge above 3.8 volts is indicated by both blue and orange lights. when the K2 fully charges the LED will flash blue and orange 20 times. When you unplug your K2 the button will flash blue and orange three times.



aspire®

User manual for K2 Quick Start kit

Thank you for choosing the Aspire K2 Quick Start kit. This simple and convenient kit just needs ejuice and you're ready to go. The K2 kit features usb charging and a refillable tank. Using Aspire's Bottom Vertical Coil technology the K2 will give you an amazing mouth to lung experience with flavor that no cigarette can match.

Instructions

1. Pressing the fire button five times within two seconds will turn on and off the K2 battery. The fire button will flash blue and orange three times to indicate off or on.
2. When the K2 is in use the light on the button will indicate your K2's current charge. When the K2's current charge capacity is above 3.8 volts the fire button will be blue and orange. When the charge is between 3.8 and 3.5 volts the button will be blue only. When the charge drops below 3.5 volts the light will then become orange to remind you that it is time to charge your K2.

