

aspire®

# Breeze 2 USER MANUAL

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the age of 18 years, pregnant or breast feeding women and those experiencing general ill health.




## Contents

- 1\* Breeze 2 device
- 2\* Coils (1\*1.0Ω/1\*0.6Ω)
- 4\* Extra O rings
- 1\* Silicone seal
- 1\* Micro USB Cable
- 1\* Warranty Card
- 1\* User Manual

## Specifications

Breeze 2 Pod capacity: 3.0ml  
Breeze 2 coil is interchangeable with original Breeze coils  
Built-in Battery Capacity: 1000mAh  
Dimensions: 95\*35\*19mm  
Adjustable airflow  
Easy bottom fill  
Bypass Output



## Breeze 2 Filling

1. Squeeze the pod release buttons on each side of the device to release and remove the pod system.
2. Invert the pod and lift the silicon seal.
3. Place the filling bottle/dropper into the pod filling hole.
4. Squeeze the filling bottle/dropper bulb to add your preferred e-juice into the pod system.
5. Replace the silicone seal firmly.
6. Re-inset the pod into the power unit, and push down firmly until it 'clicks' into place.



## Breeze 2 Coil Installation

1. Pull and remove the drip tip section.
2. Unscrew and pull out the chimney unit.
3. Detach the atomizer from the airflow control ring and replace it with a new one.
4. Screw the chimney unit back to the pod system.
5. Replace the drip tip section.



**Note:** To adjust the airflow of the Breeze 2, please remove the mouth piece and rotate the airflow control ring on top of the Breeze 2 pod.

## Instructions

- Pressing the fire button five times within two seconds will turn the device on or off. The indicator lights at the bottom

of the pod system will flash blue and orange three times to indicate off or on.

- When the Breeze 2 is on press the fire button, the light will indicate your Breeze 2's current charge. When its current charge capacity is above 3.8 volts the indicator lights will be blue and orange. When the charge is between 3.8 and 3.5 volts the light will be blue only. When the charge drops below 3.5 volts the light will then become orange to remind you that it is time to charge your Breeze 2.

## Protective Features

- Automatic Cutoff: The preset continuous fire time is 10 seconds, after 10 seconds of continuous firing, the breeze 2 will stop firing, it will fire again when the button is pressed.
- Short Circuit Protection: When the Breeze 2 detects a short, it will stop firing, and the LED light will flash blue and orange 2 or 3 times depending on where the short has occurred.
- Low Voltage Protection: When the battery level drops below 3.2V, the Breeze 2 will not function and the LED light will flash orange 15 times to remind you to charge your Breeze 2.
- Overcharge Protection: When the Breeze 2 is fully charged, it will stop charging to prevent overcharging of your battery.

## Charging Instructions

- Charge via the Micro USB port. Maximum charge current can reach up to 800mA.
- When the usb cable is attached the Breeze 2 indicator light will flash blue and orange three times. While charging the LED will indicate the Breeze's current charge

status: 3.5 volts or less= orange light; 3.5 to 3.8 volts= blue light; 3.8 volts and above –both blue and orange lights. When the Breeze 2 is fully charged the LED will flash blue and orange 20 times then remain off.

## IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

## NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

## WARNINGS AND PRECAUTIONS

Nicotine containing e-liquids are not recommended for:

- Non-smokers
- Young people under the age of 18 years;
- Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;
- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
- Those who have an overactive thyroid gland or have a phaeochromocytoma(a tumour of the adrenal gland that can affect high blood pressure);
- Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication;
- Theophylline (to treat breathing problems)
- Ropinirole (to treat restless legs)
- Clozapine (to treat schizophrenia)

## POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much you may experience one or more of the following effects:

- Feeling faint;
- Nausea (feeling sick)
- Headache
- Coughing
- Irritation of the mouth or throat
- Dizziness
- Stomach discomfort
- Hiccups
- Nasal congestion
- Vomiting (being sick)
- Heart palpitations
- Abnormal heart rate

If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

To learn more about your products and how to use, please visit: [www.aspirecig.com](http://www.aspirecig.com)

Shenzhen Eigate Technology Co., Ltd.

Building 3, Xinhongtai Industrial Park, 14 Jian'an Rd, Tangwei, Fuyong Town, Bao'an District, Shenzhen, China  
Tel: +86-755-81499783 Email: [service@aspirecig.com](mailto:service@aspirecig.com)

Manufactured By Eigate MADE IN CHINA

