

aspire®

Nautilus 2S User Manual

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with e-liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the age of 18 years, pregnant or breast feeding women and those experiencing general ill health.



Keep out of reach of children and minors!

This product contains nicotine which is a highly addictive substance.

The above warning only applies when this device has been filled with nicotine containing e-liquid

Contents:

- 1* Nautilus 2S tank
- 1* Extra drip tip
- 2* Coil (1*0.4Ω & 1*1.8Ω preinstalled)
- 10* O-rings
- 1* Warranty Card
- 1* User Manual

Nautilus 2S tank features

- Super easy top fill
- Child resistant
- 2ml capacity
- Bottom adjustable airflow
- Coil resistance: 0.4Ω (23-28W), 1.8Ω (10-14W)
- Super efficient wicking
- Great vapor and flavor production
- Compatible with Nautilus BVC coils
- Suitable for both MTL hits and restricted lung hits
- Diameter: 23mm
- Length (including stainless drip tip): 61.5mm

Tank filling

- Partially unscrew the top cap to loosen.
- Place your thumb on the top cap right above the triangle symbol and push the top cap away until the filling hole is revealed.
- Add your preferred e-liquid by pushing the tip of your filling bottle through the larger hole in the silicon leak resistant seal.
- Push the top cap back into place.
- Screw down the top cap to seal.

1



- When using a new atomizer, let the tank stand for 5 minutes after filling so the cotton can be saturated with e liquid before use.
- Do not let the tank become completely empty. Refill the tank to avoid dry burning or damage to the atomizer.

Coil installation

- Invert the tank and unscrew to remove the base hardware.
- Push down the child-proof mechanism and unscrew to disengage the child-proof coil component.
- Detach the used coil and replace it with a new one.
- Insert the child-proof coil component into the tank, then push down and screw in to relocate the child-proof coil component.
- Screw the base hardware back to the tank.

2



IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

WARNINGS AND PRECAUTIONS

Nicotine containing e-liquids are not recommended for:

3

- Non-smokers
- Young people under the age of 18 years;
- Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;
- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
- Those who have an overactive thyroid gland or have a phaeochromocytoma (a tumour of the adrenal gland that can affect high blood pressure);
- Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication;
 - Theophylline (to treat breathing problems)
 - Ropinirole (to treat restless leg syndrome)
 - Clozapine (to treat schizophrenia)

POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much you may experience one or more of the following effects:

- Feeling faint;
- Nausea (feeling sick)
- Headache
- Coughing
- Irritation of the mouth or throat

4

- Dizziness
- Stomach discomfort
- Hiccups
- Nasal congestion
- Vomiting (being sick)
- Heart palpitations
- Abnormal heart rate

If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.



*Diameter of the pod refill hole.

To learn more about your products and how to use, please visit: www.aspirecig.com

Shenzhen Eigate Technology Co., Ltd.

Building 3, Xinhongtai Industrial Park, 14 Jian'an Rd, Tangwei, Fuyong Town, Bao'an District, Shenzhen, China
Tel: +86-755-81499783 Email: service@aspirecig.com



5